



tende & scorritenda

art. 5331

A

# Art. 5331 Ref. 5331

PULSANTE DIGITALE PER 1 MOTORE, CENTRALINA O GRUPPO  
DIGITAL BUTTON FOR 1 MOTOR, CONTROL BOX OR GROUP  
BUOTOM NUMERIQUE POUR 1 MOTEUR, CENTRALE OU GROUPE  
PULSADOR DIGITAL PARA 1 MOTOR, CENTRALINA O GRUPO  
DIGITALE SCHALTER FUR 1 MOTOR, STEUERGERAT ODER GRUPPENSTEUERUNG  
DIGITALE DRUKKNOP VOOR 1 MOTOR, REGELEENHEDEN OF GROEP  
ЦИФРОВАЯ КНОПКА ДЛЯ ДВИГАТЕЛЯ, БЛОКА ИЛИ ГРУППЫ

Z 248/1 rev. A




Fig. 1A




Fig. 2A





Fig. 3A




Fig. 4A



tende & scorritenda

art. 5331






Fig. 1B

Art. 5331

COMANDO SINGOLO  
**SINGLE CONTROL**  
ОДИНОЧНОЕ УПРАВЛЕНИЕ

Art. 5331 LD







Fig. 2B



- "▶" - "▲" ATTIVAZIONE 1 - ACTIVATION 1 - ACTIONNEMENT 1 - ACTIVACION 1  
AKTIVIERUNG 1 - ACTIVERING 1 - ВКЛЮЧЕНИЕ 1
- "◀" - "▼" ATTIVAZIONE 2 - ACTIVATION 2 - ACTIONNEMENT 2 - ACTIVACION 2  
AKTIVIERUNG 2 - ACTIVERING 2 - ВКЛЮЧЕНИЕ 2
- "■" ARRESTO - STOP - ARRKTE - INTERRUPCION  
STOPPEN - STOP - ВЫКЛЮЧЕНИЕ

Z 248/1 rev. A



COMANDO DI GRUPPO  
**GROUP CONTROL**  
ГРУППА

MAX 20 ARTICOLI  
MAXIMUM 20 ITEMS  
20 ARTICLES MAXIMUM  
20 ARTICULOS MAXIMO  
MAXIMUM 20 ARTIKEL  
MAXIMUM 20 STUKS  
MAX 20 АРТИКУЛОВ






Fig. 3B



- "▶" - "▲" ATTIVAZIONE 1 - ACTIVATION 1 - ACTIONNEMENT 1 - ACTIVACION 1  
AKTIVIERUNG 1 - ACTIVERING 1 - ВКЛЮЧЕНИЕ 1
- "◀" - "▼" ATTIVAZIONE 2 - ACTIVATION 2 - ACTIONNEMENT 2 - ACTIVACION 2  
AKTIVIERUNG 2 - ACTIVERING 2 - ВКЛЮЧЕНИЕ 2
- "■" ARRESTO - STOP - ARRKTE - INTERRUPCION  
STOPPEN - STOP - ВЫКЛЮЧЕНИЕ