



tende & scorritenda

art. 5361

A

ART. 5361

PULSANTE DIGITALE PER 1 O 2 MOTORI, CENTRALINE O GRUPPI
 DIGITAL BUTTOM FOR 1 OR 2 MOTORS, CONTROL BOXES OR GROUPS
 BUOTOM NUMERIQUE POUR 1 OU 2 MOTEURS, CENTRALES OU GROUPEES
 PULSADOR DIGITAL PARA 1 OU 2 MOTORES, CENTRALINAS O GRUPOS
 DIGITALE SCHALTER FUR 1 ODER 2 MOTOREN, STEUERGERATE ODER GRUPPENSTEUERUNG
 DIGITALE DRUKKNOP VOOR 1 OF 2 MOTOREN, REGELEENHEDEN OF GROEPEN
 ЦИФРОВАЯ НОПКА ДЛЯ 1 ИЛИ 2 ДВИГАТЕЛЕЙ, БЛОКОВ ИЛИ ГРУПП

Z 248 rev. A




Fig. 1A




Fig. 2A





Fig. 3A




Fig. 4A



tende & scorritenda

art. 5361





Fig. 1B

Art. 5361

Z 248 rev. A







Fig. 2B

220 Vac - 50 Hz
110 Vac - 60 Hz

SINGOLO
SINGLE
ОДИНОЧНОЕ
УПРАВЛЕНИЕ


- "◀" - "▶" ATTIVAZIONE 1 - ACTIVATION 1 - ACTIONNEMENT 1 - ACTIVACION 1
AKTIVIERUNG 1 - ACTIVIERING 1 - ВКЛЮЧЕНИЕ 1
- "▲" - "▼" ATTIVAZIONE 2 - ACTIVATION 2 - ACTIONNEMENT 2 - ACTIVACION 2
AKTIVIERUNG 2 - ACTIVIERING 2 - ВКЛЮЧЕНИЕ 2
- "■" ARRESTO - STOP - ARRKTE - INTERRUPCION
STOPPEN - STOP - ВЫКЛЮЧЕНИЕ



MAX 5 ARTICOLI
MAXIMUM 5 ITEMS
5 ARTICLES MAXIMUM
5 ARTICULOS MAXIMO
MAXIMUM 5 ARTIKEL
MAXIMUM 5 STUKS
MAX 5 АРТИКУЛОВ

GRUPPO 1
GROUP 1
ГРУППА 1



GLI ARTICOLI DEVONO ESSERE UGUALI
THE ARTICLES MUST BE THE SAME
LES ARTICLES DOIVENT ETRE PAREILS
LOS ARTICULOS DEBEN SER IGUALES
DIE ARTIKEL MUSSEN DIESELBEN SEIN
DE STUKS MOETEN IDENTIEK ZIJN
ВСЕ АРТИКУЛОВ ДОЛЖНЫ БЫТЬ ОДИНАКОВЫМИ



MAX 5 ARTICOLI
MAXIMUM 5 ITEMS
5 ARTICLES MAXIMUM
5 ARTICULOS MAXIMO
MAXIMUM 5 ARTIKEL
MAXIMUM 5 STUKS
MAX 5 АРТИКУЛОВ

GRUPPO 2
GROUP 2
ГРУППА 2

GLI ARTICOLI DEVONO ESSERE UGUALI
THE ARTICLES MUST BE THE SAME
LES ARTICLES DOIVENT ETRE PAREILS
LOS ARTICULOS DEBEN SER IGUALES
DIE ARTIKEL MUSSEN DIESELBEN SEIN
DE STUKS MOETEN IDENTIEK ZIJN
ВСЕ АРТИКУЛОВ ДОЛЖНЫ БЫТЬ ОДИНАКОВЫМИ



"◀" - "▶" SELEZIONE - SELECTION - SELECTION - SELECCION
ANWAHL - SELECTIE - ВЫБОР

"▲" - "▼" ATTIVAZIONE - ACTIVATION - ACTIONNEMENT - ACTIVACION
AKTIVIERUNG - ACTIVIERING - ВКЛЮЧЕНИЕ

"■" ARRESTO - STOP - ARRETE - INTERRUPCION
STOPPEN - STOP - ВЫКЛЮЧЕНИЕ

Fig. 3B

220 Vac - 50 Hz
110 Vac - 60 Hz

220 Vac - 50 Hz
110 Vac - 60 Hz

220 Vac - 50 Hz
110 Vac - 60 Hz

220 Vac - 50 Hz
110 Vac - 60 Hz