


Rollbox 140




Z371 Foglio istruzioni Rollbox 140


1



2




3




4



5



REGOLAZIONE CARICA DELLA MOLLA - HOW TO REGULATE SPRING CHARGE - COMO REGULAR LA CARGA DE LA MUELLE - REGULAÇÃO DA TENSÃO DA MOLLA - RÉGLAGE DE LA TENSION DU RESSORT - EINSTELLUNG DER FEDERSpannung - REGULING VAN DE VEERSpanNING - РЕГУЛИРОВКА НАТЯЖЕНИЯ ПРУЖИНЫ




Rollbox 140




Z371 Foglio istruzioni Rollbox 140

6





7

Ref. 4633N



8a

Ref. 4632B





Rollbox 140



Z371 Foglio istruzioni Rollbox 140




8b

Ref. 4617N



9b

Ref. 4617N



MOTTURA S.p.A.
Via XXV Luglio, 1
10090 - San Giusto Canavese (To) Italia
Tel. (0039) 0124.49.49.4
Fax (0039) 0124.49.49.18

Internet: www.mottura.com
E-mail: mottura@mottura.com